



Rd-60-Kit Specification

Version V2.0.0

Copyright ©2025

Document resume

[illegible]

Content

1. Product Overview	4
1.1. Characteristic	5
2. Main parameters	6
2.1. Power supply selection	6
2.2. Static electricity requirements	6
2.3. Power consumption	7
3. Appearance size	8
4. Interface Description	9
4.1. Indicator Light Description	9
4.2. LED selection port description	10
4.3. Power Supply Selection Instructions	10
4.4. Power Select Switch Description	11
4.5. Command interface description	12
4.6. Data interface description	12
4.7. Function selection dip switch description	12
4.8. Reset Button Description	13
4.9. Wake-up button description	13
4.10. UPD Burn Button Description	14
4.11. Rd-61 Interface Description	14
4.12. Rd-60 Interface Description	14
4.13. Double-row pin interface description	15
5. Installation method	17
6. Schematic	18
7. Packing information	19
8. Contact us	19
Disclaimer and copyright notice	20
Notice	20
Statement	21

1. Product Overview

Rd-60-Kit is a radar test board developed by Shenzhen Ai-Thinker Technology Co., LTD. It is compatible with two 60GHz FMCW millimeter-wave radar modules, Rd-60 and Rd-61 are designed to facilitate developers to evaluate and design solutions.

Rd-60-Kit allows developers to connect a variety of peripherals to meet the development of various application scenarios. It is especially suitable for applications such as smart home, smart appliances, smart security, and smart lighting. Its ultra-low power consumption can bring longer battery life to battery products.

Rd-60-Kit has three LED lights, three buttons, two radar sockets, a power selection switch, a function selection dip switch and two Type-C interfaces.

The main components and application connections of Rd-60-Kit are shown in the figure below:




Figure 1 Schematic diagram of Rd-60-Kit hardware connection

1.1. Characteristic

- Supports two radar modules, Rd-60 and Rd-61
- Equipped with a host computer for point cloud data detection and parameter adjustment
- Three status indicators, one red, one blue and one green, corresponding to the different states of Rd-60-Kit
- Dual TTL interface, supports command sending and data output at the same time
- Supports low power consumption test
- Brings out all available interfaces

2. Main parameters

Table 1 main parameters

Model	Rd-60-Kit
Size	42.0*70.0(±0.2)mm
Operation temperature	-20°C~70°C
Storage environment	-40°C~ 125°C,<90%RH
Power supply	Supply voltage 1.7V ~ 5.5V, typical value 3.3V, supply current ≥500mA
Supported radar interface	Rd-60 , Rd-61
Indicator Light	3PCS (1 red, 1 blue, 1 green)

2.1. Power supply selection

Rd-60-Kit supports 2 power supply modes:

- ✓ Type-C port power supply (recommended)
- ✓ Pin header power supply

2.2. Static electricity requirements

Rd-60-Kit is an electrostatic sensitive equipment, special precautions should be taken during handling.



Figure 2 ESD anti-static diagram

2.3. Power consumption

All power consumption data below is based on an ambient temperature of 25°C, low power firmware, and 3.3V power to the board headers via a power monitor (Power Monitor BLU 939).

Table 2 Power consumption

Mode	Min.	AVG.	Max.	Unit
Rd-60-Kit base plate	-	30.74	-	μA
Equipped with Rd-60 unmanned state	-	77.82	-	μA
Equipped with Rd-60 manned state	-	1.67	-	mA
Equipped with Rd-61 unmanned state	-	56.25	-	μA
Equipped with Rd-61 manned state	-	1.67	-	mA

4. Interface Description




Figure 5 Rd-60-Kit interface diagram

4.1. Indicator Light Description




Figure 6 Indicator Light Diagram

- The LED ports are not marked in the schematic diagram, so please add a note here.
- ✓ LED1: Connect to RD-60's PA13
- ✓ LED2: Connect to RD-60's PA12 and RD-61's PA0
- ✓ LED3: Power indicator light

- How to use the indicator light?
- ✓ LED1: Reserved interface
- ✓ LED2: Used to indicate the presence of human body, applicable to Rd-60 and Rd-61

4.2. LED selection port description

- Because the LED of Rd-61 uses PA0, and Rd-60 uses PA12, this LED selection port is designed to enable the LED status indicator of Rd-61.




Figure 7 LED selection port diagram

- Instructions for use
- ✓ When the Rd-60 module is connected, this interface can be short-circuited continuously.
- ✓ When connected to the Rd-61 module, this interface should be short-circuited to enable the status indicator

4.3. Power Supply Selection Instructions




Figure 8 Power supply selection diagram

- The power supply options are divided into two groups:
- ✓ V13 selection port: Power the module's V13 port at a voltage of 1.3V

- ✓ VCC selection port: external input 3.3V or 5V interface

If VCC has no external input requirements, please short-circuit VCC and VCC-3V3!

■ Instructions for use

V13 interface, when you need to supply 1.3V voltage to the V13 port of the module, it must be short-circuited.

If you need to use super low power consumption, you must short-circuit this interface, otherwise you cannot achieve the lowest power consumption.

- VCC interface, this is the power input interface of the development board, the power supply range is 3.3V~5V. External power supply voltage can be connected through the VCC interface. This interface needs to be used with a 3V3 switch.
- ✓ When VCC input is 3.3V, the 3V3 switch selects the VCC terminal.
- ✓ When VCC inputs 5V, the 3V3 switch selects the VCC-3V3 terminal.

4.4. Power Select Switch Description



Figure 9 Schematic diagram of the power selection switch

- This is a GPIO voltage (VDDIO) selection switch, which provides a reference level for the module's GPIO, fixed at 3.3V.
- ✓ VCC-3V3 : Onboard 3.3V power supply
- ✓ VCC: External input power supply, voltage is 3.3V~5V
- Instructions for use:

- ✓ When the VCC input of the power selection port is 5V, the switch should select VCC-3V3
- ✓ When the VCC input of the power selection port is 3.3V, the switch can select the VCC terminal.

4.5. Command interface description

- The UART0 Type-C port of the development board is the command port of the module, and control commands can be sent to the module through this port.
- Use a Type-C data cable to access this port and connect it to a PC for use.

If the port cannot be recognized, please check the driver!

4.6. Data interface description

- The UART1 Type-C port of the development board is the radar data output port of the module, and the host computer interacts with this port for radar data.
- Use a Type-C data cable to access this port and connect it to a PC for use.

If the port cannot be recognized, please check the driver!

4.7. Function selection dip switch description




Figure 10 Schematic diagram of function selection dip switch

- This is a communication interface selection switch for UART0 and UART1. It can be used to select whether to use the Type-C interface of UART0 or UART1 for communication. The corresponding relationship is as follows:

Table 3 DIP switch function table

No.	GPIO	Functionality after enabling
1	PB0	TX0 (UART0_TXD, no distinction)
2	PB1	RX0 (UART0_RXD, no distinction)
3	NC	Dangling
4	PA6	RTS1(Rd-60 UART1_RTS)
5	PA7	CTS1(Rd-60 UART1_CTS)
6	PA8	TX1(Rd-60 UART1_TXD)
7	PA9	RX1(Rd-60 UART1_RXD)
8	PA0	TX1(Rd-61 UART1_TXD)

■ Instructions for use

- ✓ UART0 serial port: UART0 serial port does not distinguish between modules, Rd-60 and Rd-61 can be used, so it is enabled by default and the switch is turned to NO.
- ✓ UART1 serial port: Enable when you need to use UART1 to output radar data. If you are using Rd-61, just turn PA0 to NO.

4.8. Reset Button Description

- A touch switch used to manually reset the module, effective at low level.
- Press and release the button to reset the module.

4.9. Wake-up button description

- When the module is in deep sleep and IO wake-up is set, it is used, and low level is effective. (Reserved interface)

- Wake-up button access PA10, Just press the button and release it.

4.10. UPD Burn Button Description

- Used to control the module to enter the burning mode, low level is effective.
- After pressing the burn button, unplug and replug the Type-C data cable to enter the burn mode.

Because the module's reset function is not a hardware reset, the burn button + reset button cannot put the module into burn mode! You must power it on again!

4.11. Rd-61 Interface Description

- The interface for installing the Rd-61 module is an 8-pin female header with a pitch of 1.27mm.
- The Rd-61 module can be inserted according to the installation diagram.

4.12. Rd-60 Interface Description

- The interface for installing the Rd-60 module is a 24-pin female header with a pitch of 1.27 mm.
- The Rd-60 module can be inserted according to the installation diagram.

4.13. Double-row pin interface description




Figure 11 Schematic diagram of double-row pins

Table 4 Pin Definition

No.	Name	Functional Description
1	GND	(G), Ground
2	PA12	(IO/WUP),PA12,WIO12,UART2-RX,UART1-RTS,PWM4,GPADC4
3	PA13	(IO/WUP),PA13,WIO13,UART2-TX,MCO-CLK,PWM5,GPADC5
4	PA3	(IO),PA3,WIO3,SPI0-MISO,UART1-CTS,I2C0-SCL,UART2-RX,PWM3
5	PA1	(IO),PA1,WIO1,SPI0-CLK,UART1-RX,PWM1
6	PA2	(IO),PA2,WIO2,SPI0-MOSI,UART1-RTS,I2C0-SDA,UART2-TX,PWM2
7	NRST	(IO), External reset, low level is effective, default high level

8	PA0	(IO),PA0,WIO0,SPI0-CS,UART1-TX,PWM0,MCO-CLK
9	V13	(PI), Analog power input voltage 1.2V~2.5V, default 1.5V, NC
10	VDDIO	(PI), module IO power supply 1.7~3.6V, default input 3.3V
11	VCC	(PI), module power supply 1.7V~5.5V, default input 3.3V
12	GND	(G), Ground
13	GND	(G), Ground
14	PB1	(IO/WUP),PB1,WIO17,UART0-RX,S-SWD-TCK,PWM1
15	PB0	(IO/WUP),PB0,WIO16,UART0-TX,S-SWD-TMS,PWM0
16	PA7	(IO/WUP),PA7,WIO7,UART1-CTS,UART2-RX,I2C1-SCL,PWM7,GPADC7
17	PA6	(IO/WUP),PA6,WIO6,UART1-RTS,UART2-TX,I2C1-SDA,PWM6,GPADC6
18	PA4	(IO),PA4,WIO4,SPI0-HOLD,I2C0-SDA,PWM4
19	PA5	(IO),PA5,WIO5,SPI0-WP,I2C-SCL,PWM5
20	PA11	(IO/WUP),PA11,WIO11,I2C1-SCL,S-SWD-TCK,PWM3,GPADC3
21	PA10	(IO/WUP),PA10,WIO10,I2C1-SDA,S-SWD-TMS,PWM2,GPADC2
22	PA9	(IO/WUP),PA9,WIO9,UART1-RX,I2C1-SDA,PWM1,GPADC1
23	PA8	(IO/WUP),PA8,WIO8,UART1-TX,I2C1-SCL,PWM0,GPADC0
24	GND	(G), Ground

5. Installation method

Rd-60-Kit has two radar interfaces. The installation method of Rd-60 and Rd-61 is shown in the figure below.




Figure 12 Rd-60 installation diagram




Figure 13 Rd-61 installation diagram

Table 5 Radar interface parameters

Rd-60	1.27mm pitch 24Pin female header
Rd-61	1.27mm pitch 8Pin female header

6. Schematic




Figure 14 Schematic diagram

7. Packing information

Table 6 Packaging Information

Packing list	Packing method	Quantity per package (static bag)	Quantity per pack (sealed bag)
Rd-60-Kit	Foam + anti-static bag	1pcs	20pcs

8. Contact us

[Ai-Thinker official website](#)

[Official Forum](#)

[Develop DOCS](#)

[LinkedIn](#)

[Tmall shop](#)

[Taobao shop](#)

[Alibaba shop](#)

[Technical support Email: support@aithinker.com](#)

[Domestic business cooperation: sales@aithinker.com](#)


[Overseas business cooperation: overseas@aithinker.com](#)

Company address: Room 403,408-410, Block C, Huafeng Smart Innovation Port, Gushu 2nd Road, Xixiang, Baoan District, Shenzhen.

Tel: 0755-29162996



Ask Ai-Thinker



WeChat official

Disclaimer and copyright notice

The information in this article, including the URL address for reference, is subject to change without notice.

The document is provided "as is" without any guarantee responsibility, including any guarantee for merchantability, suitability for a specific purpose, or non-infringement, and any guarantee mentioned elsewhere in any proposal, specification or sample. This document does not bear any responsibility, including the responsibility for infringement of any patent rights arising from the use of the information in this document. This document does not grant any license for the use of intellectual property rights in estoppel or other ways, whether express or implied.

The test data obtained in the article are all obtained from Ai-Thinker's laboratory tests, and the actual results may vary slightly.

All brand names, trademarks and registered trademarks mentioned in this article are the property of their respective owners, and it is hereby declared.

The final interpretation right belongs to Shenzhen Ai-Thinker Technology Co., Ltd.

Notice

Due to product version upgrades or other reasons, the contents of this manual may be changed.

Shenzhen Ai-Thinker Technology Co., Ltd. reserves the right to modify the contents of this manual without any notice or prompt.

This manual is only used as a guide. Shenzhen Ai-Thinker Technology Co., Ltd. makes every effort to provide accurate information in this manual. However, Shenzhen Ai-Thinker Technology Co., Ltd. does not guarantee that the contents of the manual are completely free of errors. All statements and information in this manual. And the suggestion does not constitute any express or implied guarantee.

Statement

Ai-Thinker may provide technical and reliability data (including data sheets), design resources (including reference designs), application or other design recommendations, network tools, safety information and other resources (the "Resources") "as is" without warranties of any kind, express or implied. Including, but not limited to, express or implied warranties of suitability, fitness for a particular use, or non-infringement of any third party's intellectual property rights. And specifically declares that it is not liable for any necessary or incidental losses, including but not limited to, arising from the application or the use of any of our products and circuits.

Ai-Thinker reserves the right to release information in this document (including but not limited to metrics and product descriptions) and any changes to our products without prior notice. This document automatically supersedes and replaces all information provided in previous versions of the same document number file.

These resources are available to skilled developers who design with Ai-Thinker products. You are solely responsible for: (1) Selecting the appropriate Ai-Thinker products for your application; (2) Design, validate, and run your application and product throughout its life cycle; (3) Ensure that your application meets all applicable standards, codes and laws, as well as any other functional security, information security, regulatory or other requirements.

Ai-Thinker may authorize you to use these resources only for the development of applications of Essence Products described in this Resource. Without the permission of Ai-Thinker, any unit or individual shall not extract or copy part or all of these resources, and shall not be transmitted in any form. You are not entitled to use any other Ai-Thinker intellectual property rights or any third party intellectual property rights. You shall indemnify you in full for any claims, damages, costs, losses and liabilities arising against Ai-Thinker or its representatives in connection with the use of these resources, for which Ai-Thinker is not liable.

The products offered by Ai-Thinker are subject to the terms of sale of Ai-Thinker or other applicable terms attached to Essence's products. Essence's availability of these resources does not extend or otherwise change the warranties or warranties disclaimers applicable to product releases.