



Rd-01 Specification

Version V1.1.0

Copyright ©2023



Document resume

Version	Date	Develop/revise content	Edition	Approve
V1.1.0	2023.03.24	First Edition	ShengXin Zhou	Ning Guan



Content

1. Product Overview4
1.1. Characteristic
2. Main parameters
2.1. Static electricity requirements
2.2. Electrical characteristics
2.3. Radar sensing range
2.4. Wi-Fi RF performance8
2.5. BLE RF performance
2.6. Power9
3. Appearance size
4. Pin definition
5. Schematic diagram 12
6. Design guidance
6.1. Application guide circuit
6.2. Recommended PCB package size
6.3. Precautions for radar installation
6.4. Installation environment requirements
6.5. Installation mode and induction range
6.6. Power Supply
6.7. GPIO17
7. Storage conditions
8. Reflow welding curve diagram
9. Product package information
10. Contact us
Disclaimer and copyright notice
Notice
Statement 21



1. Product Overview

Rd-01 is a radar module developed by Shenzhen Anxinke Technology Co., LTD. The module supports Wi-Fi&BLE.

Radar part is equipped with the S3KM111L chip of Sidian Micro. S3KM111L is an integrated monolithic single-wave sensor SoC based on FMCW radar technology. Operates in 24 GHz k band with up to 1 GHz modulation bandwidth per frequency. FMCW continuous wave is used to detect the target in the set space. Combined with radar signal processing and accurate human body sensing algorithm, high sensitivity human presence state sensing can be realized to recognize human body in motion and static state.

Wi-Fi&BLE is equipped with BL602 chip as the core processor and supports Wi-Fi 802.11b/g/n and BLE 5.0.The BL602 chip has a built-in low-power 32-bit RISC CPU, 276KB of RAM and a wealth of peripheral interfaces, including SPI, UART, I2C, PWM, ADC and GPIO.

Rd-01module can sense whether there is a moving or twitching human body in the area, and transmit the detection result in real time through Wi-Fi&BLE. Provide visual configuration tools, it can be easily configured with induction distance range, induction sensitivity of different sections and unmanned delay time. It also supports Wi-Fi&BLE wireless configuration of radar parameters, greatly improving the efficiency of construction and operation and maintenance, convenient and fast.




Figure 1 S3KM111L






Figure 2 BL602 chip architecture diagram

1.1. Characteristic

- SMD-12 package, compatible with standard socket or pin interface
- Radar support 24 GHZ ISM frequency band
- The radar's max sensing range is up to 5 meters
- Radar Angle is big, range of ± 60 degrees
- Radar range and accurate recognition, support induction range, shielding range outside interference
- It can realize the intelligent parameter adjustment of radar through Bluetooth, convenient and fast
- Support roof, hang a wall to install a variety of ways
- Supports IEEE 802.11 b/g/n agreement
- Wi-Fi security support WPS/WEP/WPA/WPA2 Personal/WPA3
- Support 20 MHZ bandwidth, the highest rate of 72.2 Mbps



- Bluetooth low energy 5.0, Bluetooth Mesh
- Support Station + BLE model 、Station + SoftAP + BLE model
- Support 32-bit RISC CPU, 276KB RAM
- Secure startup, supports the use of ECC 256 signature image
- Support QSPI/SPI Flash instant AES decryption (OTFAD), support AES 128 CTR mode
- Support AES 128/192/ bit encryption engine
- Support SHA-1/224/256
- Support for real random number generators (TRNG)
- Public key Accelerator (PKA), support the basic operation of large numbers, software provides the signature, authentication and so on application program interface
- Support SPI, UART, I2C, PWM, ADC and GPIO etc.
- Integration Wi-Fi MAC/BB/RF/PA/LNA/BT
- Supports a variety of sleep mode
- Supports secondary development, integrated with Windows, Linux development environment
- Assembly way flexible, compatible patch/needle/socket and so on a variety of ways
- Typical application scenario
- Human body induction lamp control
- ✓ Advertising screen devices such as the human body induction
- Life safety protection
- ✓ Smart Application
- Intelligent security



2. Main parameters

Table 1 main parameters

Model	Rd-01	
Package	SMD-12, Compatible with patch/pin/socket and other assembly methods	
Size	35.0*18.0*3.6(±0.2)mm	
Antenna	Radar: on-board antenna Wi-Fi&BLE: IPEX	
Frequency	Radar: 24G ~24.25GHz Wi-Fi: 2400 ~ 2483.5MHz	
Operation temperature	-40°C ~ 85°C	
Storage environment	-40°C ~ 125°C, < 90%RH	
Power supply	Support voltage $3.0V \sim 3.6V$, power supply current $\geq 500 \text{mA}$	
Interfaces	UART/GPIO/ADC/PWM/I2C/SPI	
I/O	8	
UART rate	Default 256000 bps	
Security	WPS/WEP/WPA/WPA2 Personal/WPA3	
Flash	Default 2MByte	

2.1. Static electricity requirements

Rd-01is an electrostatic sensitive equipment, special precautions should be taken during handling.



Figure 3 ESD anti-static diagram



2.2. Electrical characteristics

Table 2 Electrical Characteristics Table

P	arameter	Conditio	Min.	Typical value	Max.	Unit
Po	ower supply	VDD	3.0	3.3	3.6	V
	VIL	-	-	-	0.3*VDDIO	V
	VIH	_	0.7*VDDIO	_	-	V
I/O	VOL	_	-	0.1*VDDIO	-	V
	VOH	_	-	0.9*VDDIO	-	V
	IMAX	-	-	-	15	mA

2.3. Radar sensing range

Table 3 Radar induced range

Installation	Min.	Typical	Max.	Unit
Wall hanging mode ($\pm60^\circ$	-	5	-	M
Roof hanging mode	-	3.5	-	M

2.4. Wi-Fi RF performance

Table 4 Wi-Fi RF performance table

Description	Typical value			Unit		
Spectrum Range	24	100 ~ 2483.5MI	Hz	MHz		
	Output pov	ver				
Model	Min.	Typical	Max.	Unit		
11n mode HT20, PA output power	-	16	-	dBm		
11g mode, PA output power	-	17	-	dBm		
11b mode, PA output power	-	19	-	dBm		
	Receiving sensitivity					
Model	Min.	Typical	Max.	Unit		
11b, 1 Mbps	-	-98	-	dBm		
11b, 11 Mbps	-	-90	-	dBm		



11g, 6 Mbps	-	-93	-	dBm
11g, 54 Mbps	-	-76	-	dBm
11n, HT20 (MCS7)	-	-73	-	dBm

2.5. BLE RF performance

Table 5 BLE RF performance table

Description	Typical value			Unit	
Spectrum Range	2400 ~ 2483.5MHz		MHz		
	Output power				
Rate Mode	Min.	Typical value	Max.	Unit	
1Mbps	-	9	15	dBm	
Rec	Receiving sensitivity				
Rate Mode	Min.	Typical value	Max.	Unit	
1Mbps sensitivity @30.8%PER	-	-96	-	dBm	

2.6. Power

The following power consumption data is based on a 3.3V power supply and an ambient temperature of 25 $^{\circ}$ C

- Test conditions, all transmission power are completed in the antenna interface
- All emission data is based on 100% of the duty ratio, measured in continuous emission mode

Table 6 Power Consumption Table

Model	Min.	AVG	Max.	Unit
Tx 802.11b,11Mbps,POUT=+21dBm	-	260	-	mA
Tx 802.11g, 54Mbps, POUT =+18dBm	-	245	-	mA
Tx 802.11n, MCS7, POUT =+17dBm	-	230	-	mA
Rx 802.11b, 1024 bytes long	-	65	-	mA
Rx 802.11g, 1024 bytes long	-	65	-	mA
Rx 802.11n, 1024 bytes long	-	65	-	mA



3. Appearance size




Figure 4 Appearance diagram (rendering diagram is for reference only, subject to the actual object)

Note: Rd-01 module is available with and without sockets.

- The module with socket can be connected to the motherboard with a row of cables, and the installation position is flexible. Socket using standard 1 * 6 p 1.25 mm distance between interface, at the same time module of positioning hole can be used for screw fixation.
- Modules without sockets can be SMT to the motherboard, easy to improve assembly efficiency.




Figure 5 Size chart



4. Pin definition

Rd-01 connects to a total of 12 interfaces, for example, the pin diagram, the pin function definition table is the interface definition.




Figure 6 Pin diagram

Table 7 Definition table of pin functions

No.	Name	Function
1,11	GND	Ground
2	GPIO17	GPIO17/SPI_MOSI/MISO/IIC_SDA/PWM_CH2/JTAG_TCK/TMS
3	GPIO1	GPIO1/SPI_MOSI/MISO/IIC_SDA/PWM_CH1
4	GPIO2	GPIO2/SPI_SS/IIC_SCL/PWM_CH2
5	GPIO4	GPIO4/SPI_MOSI/MISO/IIC_SCL/PWM_CH4/ADC_CH1
6	GPIO5	GPIO5/SPI_MOSI/MISO/IIC_SDA/PWM_CH0/ADC_CH4/JTAG_TMS/TCK
7	CHIP_EN	By default, it is enabled on the chip. The high level is valid
8	GPIO8	Bootstrap/GPIO8/SPI_MOSI/MISO/IIC_SCL/PWM_CH3
9	GPIO16	TXD/GPIO16/SPI_MOSI/MISO/IIC_SCL/PWM_CH1/JTAG_TMS/TCK
10	GPIO7	RXD/GPIO7/SPI_SCLK/IIC_SDA/PWM_CH2/JTAG_TDO/TDI
12	3V3	3.3V power supply; It is recommended that the output current of the external power supply be at least 500mA

Note: 1. GPIO8 is used as Bootstrap. The instant of power-on is high power level, and the module enters the burning mode; The power-on moment is at low power level, and the module starts normally.



5. Schematic diagram




Figure 7 Schematic diagram



6. Design guidance

6.1. Application guide circuit




Figure 8 Application guide circuit

Note: The IO port is used as PWM. It is recommended to reserve 4.7K pull-down resistance around the module. In particular, the application of the lamp control side prevents the flash phenomenon at the moment of power-on startup.

6.2. Recommended PCB package size




Figure 9 Recommended PCB package size

Note: The Rd-01 module supports a variety of interface modes, including 1.25mm standard 6-pin socket interface, 2.0mm standard pin socket interface, and half-hole SMD patch welding.

Adopts SMD patch welding method, modules in the radar antenna back has components to avoid empty.



6.3. Precautions for radar installation

- In motherboard installation position, it is recommended that the following several ways:
- As far as possible to ensure that the radar antenna is opposite to test area, and the antenna around open without sunscreen.
- ensure that the radar installation position is firm, stable, shaking will influence the effect of detection of radar itself.
- ensure that there won't be on the back of radar object movement or vibration. Due to the penetrating nature of radar waves, the antenna signal back lobe may detect moving objects on the back of the radar. A metal shield or metal backplane can be used to shield the radar back flap to weaken the influence of objects on the back of the radar.
- The theoretical range accuracy of radar is obtained by special algorithm on the basis of the physical resolution of 0.75m. As target size, condition, different, such as RCS target distance accuracy will fluctuate; And the farthest distances fluctuate a little bit.
- In order to meet the performance of on-board antenna, antenna surrounding prohibited, metal pieces, far away from the high frequency components.

6.4. Installation environment requirements

This product needs to be installed in a suitable environment. If it is used in the following environments, the detection effect will be affected:

- Induction of continuous movement in the area of nonhuman objects, such as animals, sustained oscillation of the curtain, is the outlet of the large strain of green plant, etc.
- induction area exists the strong reflector of large area, strong reflector is ofthe radar antenna can cause interference.
- When mounting the wall, need to consider the top of the indoor air conditioning, electric fan etc. External interference factors.



6.5. Installation mode and induction range

■ Hanging roof installation




Figure 10 Schematic diagram of mounting the roof




Figure 11 Detection range of mounting roof



■ Wall mounting mode




Figure 12 Schematic diagram of wall mounting




Figure 13 Schematic diagram of detection range of wall mounting



6.6. Power Supply

- Recommended voltage is 3.3V and the peak current is above 500mA.
- Recommended to use LDO as power supply; If using DC-DC, it is recommended to control ripple within 30mV.
- DC DC power supply circuit suggested the reserved capacitance position, dynamic response can be large changes in load and optimize the output ripple.
- 3.3V power supply interface increases ESD device is recommended.




Figure 14 DC-DC step-down circuit diagram

6.7. GPIO

- Some IO ports are drawn from the periphery of the module. If necessary, it is recommended to use 10-100 ohm resistors in series on the IO ports. It can suppress overshoot, so make level both sides more smoothly. It helps EMI and ESD.
- Special IO mouth pull up or down, need to refer to instructions on the use of the specification, here will affect the launch configuration module.
- Module IO port is 3.3 V if the master IO mouth level does not match with module, need to increase the level conversion circuit.
- If IO mouth directly connected to the peripheral interface, or terminal, such as row needles, and Suggestions on the IO mouth line near the terminal obligate ESD device




Figure 15 Level switching circuit



7. Storage conditions

Products sealed in moisture-proof bags should be stored in a non-condensing atmosphere at $<40^{\circ}\text{C}/90\%\text{RH}$.

The module's moisture sensitivity level MSL is level 3.

After the vacuum bag is unwrapped, it must be used within 168 hours at 25 ± 5 °C/60%RH. Otherwise, it needs to be baked before it can be put on line again.

8. Reflow welding curve diagram




Figure 16 Reflow welding curve



9. Product package information

Rd-01 module (without socket) adopts anti-static braids packing, 550pcs/ tray. As shown in the picture below:



Figure 17 Packing braid

Table 8 Package information table

Packing List	Packaging method	Quantity per tray (tray)
Rd-01 module (with socket)	Anti-static transparent PET tray	25pcs

10. Contact us

<u>Ai-Thinker official website</u> <u>Official Forum</u> <u>Develop DOCS</u> <u>LinkedIn</u>

Tmall shop Taobao shop Alibaba shop

Technical support Email: support@aithinker.com

Domestic business cooperation: sales@aithinker.com

Overseas business cooperation: overseas@aithinker.com

Company address: Room 403,408-410, Block C, Huafeng Smart Innovation Port, Gushu 2nd Road, Xixiang, Baoan District, Shenzhen.

Tel: 0755-29162996



WeChat mini



WeChat official



Disclaimer and copyright notice

The information in this article, including the URL address for reference, is subject to change without notice.

The document is provided "as is" without any guarantee responsibility, including any guarantee for merchantability, suitability for a specific purpose, or non-infringement, and any guarantee mentioned elsewhere in any proposal, specification or sample. This document does not bear any responsibility, including the responsibility for infringement of any patent rights arising from the use of the information in this document. This document does not grant any license for the use of intellectual property rights in estoppel or other ways, whether express or implied.

The test data obtained in the article are all obtained from Ai-Thinker's laboratory tests, and the actual results may vary slightly.

All brand names, trademarks and registered trademarks mentioned in this article are the property of their respective owners, and it is hereby declared.

The final interpretation right belongs to Shenzhen Ai-Thinker Technology Co., Ltd.

Notice

Due to product version upgrades or other reasons, the contents of this manual may be changed.

Shenzhen Ai-Thinker Technology Co., Ltd. reserves the right to modify the contents ofthis manual without any notice or prompt.

This manual is only used as a guide. Shenzhen Ai-Thinker Technology Co., Ltd. makes every effort to provide accurate information in this manual. However, Shenzhen Ai-Thinker Technology Co., Ltd. does not guarantee that the contents ofthe manual are completely free of errors. All statements and information in this manual. And the suggestion does not constitute any express or implied guarantee.



Statement

Ai-Thinker may provide technical and reliability data (including data sheets), design resources (including reference designs), application or other design recommendations, network tools, safety information and other resources (the "Resources") "as is" without warranties of any kind, express or implied. Including, but not limited to, express or implied warranties of suitability, fitness for a particular use, or non-infringement of any third party's intellectual property rights. And specifically declares that it is not liable for any necessary or incidental losses, including but not limited to, arising from the application or the use of any of our products and circuits.

Ai-Thinker reserves the right to release information in this document (including but not limited to metrics and product descriptions) and any changes to our products without prior notice. This document automatically supersedes and replaces all information provided in previous versions of the same document number file.

These resources are available to skilled developers who design with Ai-Thinker products. You are solely responsible for: (1) Selecting the appropriate Ai-Thinker products for your application; (2) Design, validate, and run your application and product throughout its life cycle; (3) Ensure that your application meets all applicable standards, codes and laws, as well as any other functional security, information security, regulatory or other requirements.

Ai-Thinker may authorize you to use these resources only for the development of applications of Essence Products described in this Resource. Without the permission of Ai-Thinker, any unit or individual shall not extract or copy part or all of these resources, and shall not be transmitted in any form. You are not entitled to use any other Ai-Thinker intellectual property rights or any third party intellectual property rights. You shall indemnify you in full for any claims, damages, costs, losses and liabilities arising against Ai-Thinker its representatives in connection with the use of these resources, for which Ai-Thinker is not liable.

The products offered by Ai-Thinker are subject to the terms of sale of Ai-Thinker or other applicable terms attached to Essence's products. Essence's availability of these resources does not extend or otherwise change the warranties or warranties disclaimers applicable to product releases.