



NodeMCU-BW60-12F-Kit Specification

Version V1.1.0

Copyright ©2026



Document Revision History

Version	Date	Created / Revised Content	Prepared by	Approved by
V1.1.0	2026-06-23	First edition	Zeng Xiangfei	Xu Hong

Contents

1 Product Overview	5
1.1 Features	6
1.2 Application Scenarios	7
2 Key Specifications	8
2.1 Power Supply Selection	8
3 Electrical Characteristics	9
3.1 Recommended Operating Conditions	9
3.2 I/O DC Electrical Characteristics	9
3.3 Electrostatic Discharge	9
3.4 Wi-Fi RF Performance	10
3.5 BLE RF Performance	11
3.6 Power Consumption	12
4 Mechanical Specifications	13
4.1 Development Board Dimensions	13
5 LED and Button Description	14
6 Pin Definition	15
7 Schematic	19
8 Packaging Information	20
9 Contact Us	20
Disclaimer and Copyright Notice	21
Notice	21
Statement	22

List of Figures

Figure 1	Main Chip Architecture Diagram	5
Figure 2	ESD Protection Symbol.....	9
Figure 3	Development Board Dimensions.....	13
Figure 4	LED and Button Location	14
Figure 5	Pin Diagram (Top View).....	15
Figure 6	Pin Diagram (Bottom View).....	16
Figure 7	Schematic	19

List of Tables

Table 1	Key Specifications	8
Table 2	Recommended Operating Conditions	9
Table 3	I/O DC Electrical Characteristics.....	9
Table 4	Wi-Fi RF Performance	10
Table 5	BLE RF Performance.....	11
Table 6	Power Consumption.....	12
Table 7	LED and Button Function Description	14
Table 8	Pin Function Definition.....	16
Table 9	Packaging Information.....	20

1 Product Overview

NodeMCU-BW60-12F-Kit is a development board developed by Shenzhen Ai-Thinker Technology Co., Ltd. based on the BW60-12F module. The module uses Realtek RTL8711FA series chips as its core and integrates Wi-Fi 6 + BLE 5.4. It supports dual-band 2.4GHz and 5GHz and the 802.11 a/b/g/n/ac/ax protocols.

The RTL8711FA integrates dual RISC cores compatible with Arm Cortex-M55 instruction set under Armv8.1-M architecture, with a maximum main frequency of 320MHz. It features fine-grained clock gating, multi-power modes and dynamic power adjustment, balancing high performance and ultra-low power consumption.

The BW60-12F module features a rich set of peripheral interfaces, integrating general-purpose and sensor interfaces such as UART, SPI, I2C, CAN, ADC, RMII, capacitive touch, and temperature control. It is equipped with SDIO and USB high-speed interfaces, along with DMIC and I2S audio interfaces, and the GPIOs are flexibly configurable. It can be widely applied in IoT, mobile devices, wearable electronics, smart home and other fields.




Figure 1 Main Chip Architecture Diagram

1.1 Features

Wireless

- 2.4GHz and 5GHz RF transceiver
- Supports 802.11 a/b/g/n/ac/ax protocols
- Supports BLE 5.4
- Supports LE 1Mbps, 2Mbps
- Supports LE long-range (125kbps, 500kbps)
- Supports Arm TrustZone[®]-M
- Supports AES/SHA Engine
- Supports ECC/RSA Engine
- Supports TRNG (True Random Number Generator)
- 2K bytes OTP

Microcontroller Subsystem

- Dual 32-bit RISC cores based on the Armv8.1-M architecture
- Compatible with the Arm Cortex-M55 instruction set
- Maximum main frequency up to 320MHz

Security

- Supports secure boot and secure debug

Peripherals

- Supports USB, SPI, UART, ADC, I2C, I2S, PWM, SDIO, LEDC, IR, RMII, and GPIO, etc.

Package Type

- Adopts DIP-30 package

Development Environment

- Supports secondary development with integrated Linux development environments

1.2 Application Scenarios

- Smart Home
- Educational/Children's Toys
- Industrial Equipment Interaction
- Wearable Electronics
- Central Control Devices

2 Key Specifications

Table 1 Key Specifications

Model	NodeMCU-BW60-12F-Kit
Package	DIP-30
Dimensions	60.0*28.0 (mm)
Antenna Type	PCB onboard antenna
Frequency Range	2400 – 2483.5MHz and 5180 – 5825MHz
Operating Temperature	-40 – 85°C
Storage Conditions	-40 – 125°C, <90% RH
Power Supply Range	Supply voltage 3.3V or 5V, supply current >500mA
Available I/Os	21 by default
UART Baud Rate	921600bps by default

2.1 Power Supply Selection

The NodeMCU-BW60-12F-Kit supports three power supply modes:

- Type-C interface (recommended)
- 3V3 and GND pin header
- 5V and GND pin header

3 Electrical Characteristics

3.1 Recommended Operating Conditions

Table 2 Recommended Operating Conditions

Parameter	Condition	Min	Typ	Max	Unit
Interface Power Supply	Type-C	4.5	5	5.3	V
Pin Header Power Supply	3V3	2.97	3.3	3.63	V
	5V	4.5	5	5.3	V

3.2 I/O DC Electrical Characteristics

Table 3 I/O DC Electrical Characteristics

Symbol	Parameter	Min	Typ	Max	Unit
VIH	High-level Input Voltage	2	-	-	V
VIL	Low-level Input Voltage	-0.3	-	0.8	V
VOH	High-level Output Voltage	-	0.85*VDD	-	V
VOL	Low-level Output Voltage	-	0.15*VDD	-	V

3.3 Electrostatic Discharge

The NodeMCU-BW60-12F-Kit is an ESD-sensitive device and requires special precautions during handling.



Figure 2 ESD Protection Symbol

3.4 Wi-Fi RF Performance

Table 4 Wi-Fi RF Performance

Description	Typ			Unit
Frequency Range	2400 – 2483.5			MHz
2.4G Output Power				
Mode	Min	Typ	Max	Unit
802.11b, 1Mbps	-	21	-	dBm
802.11b, 11Mbps	-	20	-	dBm
802.11g, 6Mbps	-	20	-	dBm
802.11g, 54Mbps	-	18	-	dBm
802.11n, HT20 (MCS7)	-	18	-	dBm
802.11ax, HE20 (MCS9)	-	16	-	dBm
2.4G Receiver Sensitivity				
Mode	Min	Typ	Max	Unit
802.11b, 1Mbps	-	-99	-	dBm
802.11b, 11Mbps	-	-90	-	dBm
802.11g, 6Mbps	-	-95	-	dBm
802.11g, 54Mbps	-	-77	-	dBm
802.11n, HT20 (MCS7)	-	-76	-	dBm
802.11ax, HE20 (MCS9)	-	-70	-	dBm
Description	Typ			Unit
Frequency Range	5180 – 5825			MHz
5.8G Output Power				
Mode	Min	Typ	Max	Unit
802.11a, 6Mbps	-	18	-	dBm
802.11a, 54Mbps	-	18	-	dBm

802.11n, HT20 (MCS7)	-	18	-	dBm
802.11ax, HE20 (MCS9)	-	16	-	dBm
5.8G Receiver Sensitivity				
Mode	Min	Typ	Max	Unit
802.11a, 6Mbps	-	-92	-	dBm
802.11a, 54Mbps	-	-74	-	dBm
802.11n, HT20 (MCS7)	-	-72	-	dBm
802.11ax, HE20 (MCS9)	-	-63	-	dBm

3.5 BLE RF Performance

Table 5 BLE RF Performance

Description	Typ			Unit
Frequency Range	2400 – 2483.5			MHz
Output Power				
Data Rate Mode	Min	Typ	Max	Unit
1Mbps	-	8	15	dBm
2Mbps	-	8	15	dBm
Receiver Sensitivity				
Data Rate Mode	Min	Typ	Max	Unit
1Mbps Sensitivity @ 30.8% PER	-	-97	-	dBm
2Mbps Sensitivity @ 30.8% PER	-	-94	-	dBm

3.6 Power Consumption

The following power consumption data are measured under a 3.3V power supply and 25°C ambient temperature.

- The POUT power for all transmit modes is measured at the antenna interface.
- All transmission data are measured at 100% duty cycle in continuous transmit mode.

Table 6 Power Consumption

Mode	Min	Avg	Max	Unit
TX 802.11b, 11Mbps, POUT=+18dBm	-	273	-	mA
TX 802.11g, 54Mbps, POUT=+15dBm	-	267	-	mA
TX 802.11n, MCS7, POUT=+15dBm	-	212	-	mA
TX 802.11ax, MCS9, POUT=+13dBm	-	187	-	mA
RX 802.11b, Packet Length 1500 bytes	-	47	-	mA
RX 802.11g, Packet Length 1500 bytes	-	51	-	mA
RX 802.11n, Packet Length 1500 bytes	-	51	-	mA
RX 802.11ax, Packet Length 1500 bytes	-	51	-	mA

4 Mechanical Specifications

4.1 Development Board Dimensions




Figure 3 Development Board Dimensions

5 LED and Button Description




Figure 4 LED and Button Location

Table 7 LED and Button Function Description

No.	Function Description
①	RGB LED (The red LED is connected to PB17, the green LED is connected to PB18, and the blue LED is connected to PB19. Active high.)
②	LED lights (The upper cool LED is connected to PA19, and the lower warm LED is connected to PA20. Active high.)
③	Reset button
④	Flash button. When flashing firmware, press and hold the flash button first, then briefly press the reset button at the same time.

6 Pin Definition

The NodeMCU-BW60-12F-Kit exposes a total of 30 pins, as shown in the pin diagram. The pin function definition table provides the detailed interface specifications.




Figure 5 Pin Diagram (Top View)




Figure 6 Pin Diagram (Bottom View)

Table 8 Pin Function Definition

No.	Name	Function
1	GND	Ground
2	PA0/NC	GPIO/WAKE_PIN3; not available on the internal PSRAM version due to internal multiplexing
3	PB17	GPIO/RMII_RXERR
4	PB18	GPIO/RMII_REF_CLK/SWD_CLK
5	PB19	GPIO/RMII_RXD1/SWD_DAT
6	PA3	GPIO/WAKE_PIN0
7	PA2/LOGRXD	PA2/OTP_DIS/WAKE_PIN1; flashing port, LOG_RXD pin

8	PB20/LOGTXD	PB20/UD_DIS; flashing port, LOG_TXD pin. Also used as a boot configuration pin; see the notes below.
9	PC3/NC	GPIO/RMII_TXD1/SPI1_MOSI/SD_D0; on the external Flash version, this IO is shared with internal Flash and not exposed
10	PC2/NC	GPIO/RMII_TXEN/SPI1_CLK/SD_D2; on the external Flash version, this IO is shared with internal Flash and not exposed
11	PC7/NC	GPIO/RMII_RXD0/SD_CLK; on the external Flash version, this IO is shared with internal Flash and not exposed
12	EN	Chip enable pin, active high
13	GND	Ground
14	3V3	3.3V supply (VDD); external power supply output current recommended above 500mA
15	5V	5V supply (VBUS); external power supply output current recommended above 500mA
16	GND	Ground
17	PA26/TXD	GPIO/TSSI_1/RMII_REF_CLK/SD_D3
18	PA25/RXD	GPIO/TSSI_0/RMII_RXERR
19	PA21	GPIO/TOUCH8/SD_D3
20	PA20	GPIO/ADC0_TOUCH0/SD_D1
21	PA19	GPIO/ADC1_TOUCH1/TSSI_1/SPI0_CS/SWD_DAT/SD_CMD
22	PA18	GPIO/ADC2_TOUCH2/TSSI_0/SPI0_MISO/SWD_CLK/SD_CLK
23	PC6/NC	SPIC(0/1)_FLASH_D0/RMII_RXD1/SD_CMD; on the external Flash version, this IO is shared with internal Flash and not exposed
24	PA5/DM	GPIO/HSDM/SPI0_MOSI/SWD_DAT/SD_D0
25	PA4/DP	GPIO/HSDP/SPI0_CLK/SWD_CLK/SD_D2
26	PC5/NC	SPIC(0/1)_FLASH_CLK/GPIO/RMII_CRS_DV/SPI1_CS/SD_D3; on the external Flash version, this IO is shared with internal Flash and not exposed
27	PC4/NC	GPIO/RMII_TXD0/SPI1_MISO/SD_D1; on the external Flash version, this IO is shared with internal Flash and not exposed
28	GND	Ground

29	3V3	3.3V supply (VDD); external power supply output current recommended above 500mA
30	5V	5V supply (VBUS); external power supply output current recommended above 500mA

Notes:

1. Whether pins marked NC (no connection) are available depends on the internal PSRAM and Flash configuration of the module. On the internal PSRAM version, PA0 is unavailable. On the external Flash version, PC2, PC3, PC4, PC5, PC6, and PC7 are unavailable.
 2. If LOG_TXD is low at the moment of power-on, the module enters flashing mode. If LOG_TXD is high at the moment of power-on, the module boots normally. The module has an internal pull-up by default.
 3. Do not pull PA3 low at the moment of power-on. Pulling it low during startup will cause the module to enter Test Mode.
- Do not pull PB18 low at the moment of power-on. Pulling it low will prevent the NOR Flash from booting. The module has an internal pull-up by default.

7 Schematic




Figure 7 Schematic

8 Packaging Information

Table 9 Packaging Information

Packing List	Packaging Method	Quantity per Bag (ESD Bag)	Quantity per Bag (Sealed Bag)
NodeMCU-BW60-12F-Kit	Foam + ESD bag	1pcs	20pcs

9 Contact Us

[Official Website](#)

[Official Forum](#)

[Development DOCS](#)

[LinkedIn](#)

[Tmall Store](#)

[Taobao Store](#)

[Alibaba Store](#)

[Technical Support: support@aithinker.com](mailto:support@aithinker.com)

[Domestic Business Cooperation: sales@aithinker.com](mailto:sales@aithinker.com)

[Overseas Business Cooperation: overseas@aithinker.com](mailto:overseas@aithinker.com)

Company Address: Room 403–405, 408–410, Building C, Huaifeng Smart Innovation Port, Gushu, Xixiang, Bao'an District, Shenzhen, Guangdong, China

Contact Hotline: 0755-29162996



WeChat Mini Program



WeChat Official Account

Disclaimer and Copyright Notice

The information in this document, including referenced URLs, is subject to change without notice.

The document is provided “as is” without warranty of any kind, express or implied, including but not limited to the warranties of merchantability, fitness for a particular purpose, or non-infringement. Furthermore, no warranty is given regarding proposals, specifications, or samples mentioned elsewhere. The publisher bears no responsibility, including for any infringement of patent rights arising from the use of information contained herein. This document does not grant, expressly or impliedly, by estoppel or otherwise, any license to intellectual property rights.

All test data presented herein are obtained from Ai-Thinker laboratories. Actual results may vary slightly.

All trade names, trademarks, and registered trademarks mentioned are the property of their respective owners.

Shenzhen Ai-Thinker Technology Co., Ltd. reserves the final right of interpretation of this document.

Notice

This manual may be updated due to product version upgrades or other reasons.

Shenzhen Ai-Thinker Technology Co., Ltd. reserves the right to modify the content of this manual without prior notice or announcement.

This manual is intended as a usage guide only. While Shenzhen Ai-Thinker Technology Co., Ltd. strives to provide accurate information, it does not guarantee that the content is entirely free of errors. All statements, information, and recommendations in this manual do not constitute any express or implied warranty.

Statement

Shenzhen Ai-Thinker Technology Co., Ltd. (hereinafter “Ai-Thinker”) may provide all technical and reliability data (including datasheets), design resources (including reference designs), application or other design advice, web tools, security information, and other resources (collectively referred to as “these Resources”) on an “as is” basis, without warranty of any kind, express or implied, including but not limited to warranties of merchantability, fitness for a particular purpose, or non-infringement of any third-party intellectual property rights. Ai-Thinker specifically disclaims any liability for losses, whether direct or consequential, arising from the application or use of any Ai-Thinker products or circuits.

Ai-Thinker reserves the right to modify the content of this document (including but not limited to specifications and product descriptions) and any related products without prior notice. This document automatically supersedes and replaces all previous versions of the same document number.

These Resources are intended for use by skilled developers designing with Ai-Thinker products. You are solely responsible for: (1) Selecting the appropriate Ai-Thinker products for your application; (2) Designing, validating, and operating your application and product throughout its life cycle; (3) Ensuring your application complies with all applicable standards, laws, and any other functional safety, information security, regulatory, or other requirements.

Ai-Thinker may authorize you to use these Resources solely for developing applications incorporating the Ai-Thinker products described herein. No part of these Resources may be copied, reproduced, or distributed in any form without prior written permission from Ai-Thinker. You are not permitted to use any other intellectual property of Ai-Thinker or any third party. You shall fully indemnify Ai-Thinker and its representatives against any claims, damages, costs, losses, or liabilities arising from your use of these Resources, for which Ai-Thinker assumes no liability.

Ai-Thinker’s products are supplied under Ai-Thinker’s general sales terms and conditions or other applicable terms accompanying the products. The provision of these Resources does not expand or otherwise alter the warranties or warranty disclaimers applicable to the product as delivered.